

INSTALLATION

BrightStrip™

1. Thoroughly clean the box with denatured alcohol or a similar cleaner. Allow to dry.
2. Peel the release liner off of the LED BrightStrip and adhere to the returns according to the project specifications. BrightStrip should be positioned toward the rear of the box. See figure A below.

Adhere right-angle mounting clips as needed for tight bends.

Optimum illumination requires population around the perimeter near the back panel. As the depth of return becomes greater, the placement becomes less critical (minimum return depth - 3 inches). See figure C to the right.

3. Make necessary jumps as needed. Crimps or wire nuts should be used for connecting letters and power supplies. See figure B to the right.

Note: Black to black wire should always be connected; match colored wires appropriately. See figure B to the right.

Note: Use silicone connectors in high humidity or coastal environments.

4. Drill secondary wire holes as needed.
5. Wire in the secondary power supply voltage.
6. Test light the BrightStrip, and repeat steps 2-5 for each.

